


# Alberta Interconnected Electric System Map



## Substation Identification

Land Locations are listed by Township-Range-Meridian; Township is run South to North, Range is East to West from each Meridian and are shown in the map. Meridians are shown at the top and bottom of the map.



Updated 2025-11-12

from ACISO and associated